

Please rate this document after reviewing at the bottom of this page.


## INSPECTION

### Battery Voltage and Status

Check the battery voltage and status using the battery tester.

### Battery Terminal

1. Move back and forth to check if the battery terminals (A) are loose or corroded. If the terminals are corroded, clean them.



If battery positive connection is loose, disconnect ground(GND) cable first before attempting to remove or tighten plus connection, to prevent personal injury.

2. If the battery clamp on battery positive (+) terminal is not seated securely:
  - (1) Turn ignition switch OFF and disconnect the battery negative (-) terminal.
  - (2) Tighten battery clamp (A) on battery positive (+) terminal

**Battery positive (+) terminal:**

7.8 - 9.8 N·m (0.8 - 1.0 kgf·m, 5.8 - 7.2 lb·ft)

English ▾




3. If the battery clamp on battery negative (-) terminal is not seated securely:

(1) Tighten battery clamp (A) on battery negative (-) terminal.

**Battery negative (-) terminal:**

7.8 - 9.8 N·m (0.8 - 1.0 kgf·m, 5.8 - 7.2 lb·ft)

**Battery Condition**

Check the battery for damage or deformation. If severe damage, deformation or leakage is found, replace the battery.

\* **Thanks for your cooperation for the more quality. Please surely rate this document before closing.**