



Please rate this document after reviewing at the bottom of this page.

REMOVAL

1. Switch "OFF" the ignition and disconnect the negative (-) battery terminal.
2. Remove the RH engine mounting support bracket.
(Refer to Engine Mechanical System - "Engine Mounting")
3. Remove the stater solenoid "B" terminal mounting nut (B), and then disconnect the stater cable and ST connector (A).



4. Remove the starter mounting bolts.






INSTALLATION


1. Install in the reverse order of removal.

DISASSEMBLY


1. Disconnect the M-terminal (A) on the starter solenoid assembly.



2. After loosening the screws (A), detach the starter solenoid assembly (B).




3. Loosen the through bolts (A).




4. Remove the brush holder assembly (A), rear bracket assembly (B) after loosening the mounting screws.


5. Remove the armature assembly (C) and yoke assembly (D).




6. Remove the shield (A).



7. Remove the lever packing (A) and the planet gear (B).




8. Remove the clutch set assembly (A) and lever (B).




NOTICE


Beware of the direction of the lever (A).




9. Press the stopper (A) using a socket (B).




10. Remove the stop ring (A) using the stop ring pliers (B).



11. Remove the stopper (A), overrunning clutch (B), internal gear (C) and planet shaft (D).

**NOTICE**

Using a suitable pulling tool (A), pull the overrunning clutch stop ring (B) over the stopper (C).



REASSEMBLY

1. Reassemble in the reverse order of disassembly.


INSPECTION

Starter Solenoid Inspection

1. Disconnect the lead wire from the M-terminal of solenoid switch.
2. Connect the battery as shown. If the starter pin pops out, it is working properly.

NOTICE

- To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.




3. Disconnect the battery from the M terminal.
If the pinion does not retract, the hold-in coil is working properly.

English

NOTICE


- To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.



4. Disconnect the battery also from the body. If the pinion retracts immediately, it is working properly.

NOTICE

- To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.




Free Running Inspection

1. Place the

follows.

2. Connect a test ammeter (150-ampere scale) and carbon pile rheostats shown is the illustration.
3. Connect a voltmeter (15-volt scale) across starter motor.




4. Rotate carbon pile to the off position.
5. Connect the battery cable from battery's negative post to the starter motor body.
6. Adjust until battery voltage shown on the voltmeter reads 11.5 and 11 volts.
7. Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely.

[NON-ISG]


Items	Specification
Current (Max.)	105
Speed (Min.)	2,800

[ISG-Only]

Items	Specification
Current (Max.)	135
Speed (Min.)	3,200



4. Check the commutator (A) surface. If the surface is dirty or burnt, resurface with emery cloth or a lathe within the following specifications, or recondition with #500 or #600 sandpaper (B).




5. Measure the commutator (A) runout.
- If the commutator runout is within the service limit, check the commutator for carbon dust or brass chips between the segments.
 - If the commutator run out is not within the service limit, replace the armature.

Commutator runout

Standard (New): 0.05mm (0.0019in.) max

Service limit: 0.08mm (0.0031in.)




6. Check the mica depth (A). If the mica is too high (B), undercut the mica with a hacksaw blade to the proper depth. Cut away all the mica (C) between the commutator segments. The undercut should not be too shallow, too narrow, or v-shaped (D).

Commutator mica depth

Standard (New) : 0.8 mm (0.314 in.)


Limit : 0.2mm (0.0079 in.)



7. Check for continuity between the segments of the commutator. If an open circuit exists between any segments, replace the armature.




8. Check with an ohmmeter that no continuity exists between the commutator (A) and armature coil core (B), and between the commutator and armature shaft (C). If continuity exists, replace the armature.




Inspect Starter Brush

Any worn out or oil-soaked brushes should be replaced.




Starter Brush Holder Test

1. Check that there is no continuity between the (+) brush holder (A) and (-) plate (B). If there is continuity, replace the brush holder assembly.




2. Pry back each brush spring (A) with a screwdriver, then position the brush (B) about halfway out of its holder, and release the spring to hold it there.



3. Install the armature in the housing, and install the brush holder. Next, pry back each brush spring again, and push the brush down until it seats against the commutator, then release the spring against the end of the brush.


NOTICE

To seat new brushes, slip a strip of #500 or #600 sandpaper, with the grit side up, between the commutator and each brush, and smoothly rotate the armature. The contact surface of the brushes will be sanded to the same contour as the commutator.



Inspect Overrunning Clutch

1. Slide the overrunning clutch along the shaft.
Replace if it does not slide smoothly.
2. Rotate the overrunning clutch both ways.
Does it lock in one direction and rotate smoothly in reverse? If it does not lock in either direction or locks in both directions, replace it.



3. If the starter drive gear is worn or damaged, replace the overrunning clutch assembly. (The gear is not available separately.)
Check the condition of the flywheel or torque converter ring gear if the starter drive gear teeth are damaged.

CLEANING

1. Do not immerse parts in cleaning solvent.
Immersing the yoke assembly and/or armature will damage the insulation wipe these parts with a cloth only.
2. Do not immerse the drive unit in cleaning solvent.
The overrun clutch is pre-lubricated at the factory and solvent will wash lubrication from the clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

*** Thanks for your cooperation for the more quality. Please surely rate this document before closing.**