




Removal


1. Turn ignition switch OFF and disconnect the negative (-) battery cable.
2. Remove the front bumper assembly.
(Refer to Body - "Front bumper assembly")
3. Disconnect the SCC ECU & radar connector (A).



4. Loosen the SCC ECU & radar nuts (A) and bolt (B) and then remove the SCC ECU & radar (C).

Tightening torque:

(A,B) : 9.8 - 11.8 N·m (1.0 - 1.2 kgf·m, 7.2 - 8.7 lb·ft)



Installation

1. Install in the reverse order of removal.
2. Perform SCC variant coding.

S/W Management

Unfold All

Systems	Components
■ Engine Control	
■ Automatic Transaxle	
■ ABS/ESC	
■ SCC/AEB	
■ System Identification	
■ Variant Coding	
■ Radar Sensor Alignment (SCC/AEB)	
■ Airbag(Event #1)	
■ Airbag(Event #2)	
■ Occupant Detection Sensor	
■ Air Conditioner	
■ Motor Driven Power Steering	
■ Tire Pressure Monitoring System(High Type)	
■ Tire Pressure Monitoring System(Low Type)	
■ Parking Guide System	
■ Immobilizer	

! Do not touch any system buttons while performing this function.

S/W Management**• AEB Variant Coding**

Purpose	To initialize the Autonomous Emergency Braking(AEB) ECU.
Enable Condition	1.Engine Off 2.Ignition Switch On
Concerned Component	Smart Cruise Control(SCC) Unit
Concerned DTC	C1702
Fail Safe	Warning Lamp On
Etc	-

OK**Do not touch any system buttons while performing this function.**

S/W Management

■ Variant Coding

● [SCC Variant Coding]

[Data Write]

1. Select the item to modify.
2. Select the value in combo box.
3. Press **[OK]** button.
4. IG Key off and on after the test end.

Item	Setting Value
Drivetrain Option :	4WD
Transmission Option :	AT
Driver Seat Position :	LHD
SCC Enable Option :	ENABLE
NAVI SCC Option :	DISABLE
HDA Option :	DISABLE
AEB Enable Option :	ENABLE

!
Do not touch any system buttons while performing this function.

3. Perform the smart cuise control system (Stop & Go) unit radar alignment.
 (Refer to Engine Electrical System - "Smart cruise control (Stop & Go) unit-radar")

Smart Cruise Control (SCC) Radar Sensor Alignment

Smart Cruise Control (SCC) unit detects a forward vehicle and then recognizes the distance to the forward vehicle and the relative speed using the built-in radar sensor. In order for the radar sensor to operate correctly, it must be properly aligned parallel to the driving direction of the vehicle. So, the radar sensor alignment procedure must be carried out after the sensor is reinstalled or replaced with new one. If not performing the sensor alignment in the conditions mentioned above, the smart cruise control system may not operate correctly.

Information

The SCC radar sensor alignment is required when:

- The SCC unit is reinstalled or replaced with a new one.
- The radar sensor or the surrounding parts are impacted by a collision.
- The sensor does not recognize a forward vehicle.
- The Steering Angle Sensor (SAS) is replaced or adjusted.

NOTICE

Preparation before the SCC radar sensor alignment:

- Put the vehicle on the level ground.
- Take out heavy luggage from the vehicles' seats or trunk.
- Set all tires according to the specified pressure.
- Check wheel alignment.
- Check that the front surface of the SCC unit is clean.

Radar sensor should be aligned in both vertical and lateral direction. Vertical alignment can be performed by using the SST (0K964-3T000) and lateral alignment can be performed automatically by driving on a road.

1. Park the vehicle on a level ground.


2. Remove the front bumper assembly.

(Refer to Body - "Front Bumper Assembly")

3. Check the vertical alignment of the radar sensor using the digital level/tilt meter (A).


If the vertical alignment is out of the tolerance, turn the adjustment screw (B) until the alignment is within the tolerance.

Tolerance: $\pm 1.5^\circ$ or less



NOTICE

The vertical mounted degree should be -1° downward.



4. Install the front bumper.

(Refer to Body - "Front Bumper Assembly")

5. To perform the lateral alignment, connect the KDS with the engine started and select the “SCC Alignment”.

Information

Be sure to erase DTC before performing the lateral alignment.

S/W Management

Unfold All

Systems **Components**

■ Engine Control	
■ Automatic Transaxle	
■ ABS/ESC	
■ SCC/AEB	
■ System Identification	
■ Variant Coding	
■ Radar Sensor Alignment (SCC/AEB)	
■ Airbag(Event #1)	
■ Airbag(Event #2)	
■ Occupant Detection Sensor	
■ Air Conditioner	
■ Motor Driven Power Steering	
■ Tire Pressure Monitoring System(High Type)	
■ Tire Pressure Monitoring System(Low Type)	
■ Parking Guide System	
■ Immobilizer	

! Do not touch any system buttons while performing this function.

S/W Management	
* Radar Sensor Alignment (SCC/AEB)	
Purpose	To align radar sensor for normal operation of emergency automatic braking system.
Enable Condition	1. Engine Off 2. Ignition Switch On 3. No DTC
Concerned Component	Autonomous Emergency Braking (AEB) Module, Radar Sensor
Concerned DTC	C162078
Fail Safe	Warning Lamp On
Etc	1. When a collision accident occurs (when the sensor has received impact), check if the vertical installation angle of the radar sensor is normal (90°). 2. If necessary, adjust the angle of radar sensor to 90° using the tilt meter and star wrench (T20). 3. If no electronic tilt meter is available, adjust the angle of radar sensor using the bubble meter.
OK	

Fig.4

6. Select “Driving Mode” to start sensor alignment.

S/W Management

■ Radar Sensor Alignment (SCC/AEB)

● [Radar Sensor Alignment (SCC/AEB)]

The alignment of radar sensor is required for normal operation of emergency automatic braking system.

Cases requiring Radar Sensor Alignment (SCC/AEB)

1. When the radar sensor is replaced
2. When a collision accident occurs (when the sensor has received impact)
3. After SAS(Steering Angle Sensor) is replaced and ZeroSet is carried out
4. When the front vehicle cannot be recognized while driving
5. When Radar Alignment DTC is detected

⚠[Caution]

1. When a collision accident occurs (when the sensor has received impact), check if the vertical installation angle of the radar sensor is normal (90°).
2. If necessary, adjust the angle of radar sensor to 90° using the tilt meter and star wrench (T20).
3. If no electronic tilt meter is available, adjust the angle of radar sensor using the bubble meter.

●[Condition]

1. No DTC
2. Ignition Key ON

Setting mode
[C1] button : Stop mode
[C2] button : Driving mode

C1 C2 Cancel

Fig.5

7. Drive the vehicle and check that the yellow warning light on the cluster is turned ON and then OFF.




Fig.6

Information

The Driving mode Sensor Alignment (calibration) process has started.

- Disconnect the Diagnostic tool from the vehicle and drive the vehicle
- The red warning light will turn off automatically when the alignment calibration is successfully completed

OK

Fig.7

NOTICE

The lateral alignment takes about 5 to 15 minutes generally but it can be shorten or extended depending on the road condition or driving condition.

- Road or driving conditions for shortening the alignment :
- Driving at more than 65 km/h (40.4 mph)
- Driving on a road without curve and slope
- Driving on a thick and wide paved road
- Driving on a road where there are repetitive and fixed targets (metal materials such as street lights or guard rails)
- Driving on a dry road without rain or snow
- Road or driving conditions that can interrupt the alignment process
- Driving a road with the sharp curve where the radius is within 100m (328.0ft)
- Driving at a lower speed than suggested above or during a stop due to a red light
- Driving in a tunnel or under an overpass
- Turning the steering wheel excessively to the left or right or changing the lane suddenly

CAUTION

Be sure to follow the below safety guidelines while driving the vehicle for the lateral alignment :

- Observe a regulation speed
- Do not drive too fast for shortening the sensor alignment. Drive safely considering the road condition and traffic situation.
- Do not stare the KDS screen or operate the KDS while driving. Only while stopping, the KDS should be operated.

NOTICE

If the lateral alignment is not completed successfully, check the alignment using the KDS. If the value is out of $\pm 3^\circ$, check that the back beam or bracket where the SCC unit is mounted are in a good condition and then if there is no problems, replace the SCC unit with new one. After replacing the SCC unit, repeat the alignment procedure described above.