



Inspection

1. Switch "OFF" the ignition and disconnect the negative (-) battery terminal.
2. Disconnect the fuel pressure regulator valve connector.
3. Measure resistance between the fuel pressure regulator valve terminals 1 and 2.
4. Check that the resistance is within the specification.

Specification: 1.09 - 1.21 Ω [20°C (68°F)]

Removal

NOTICE

The fuel pressure regulator valve cannot be replaced as a unit. Replace it as high pressure fuel pump assembly.
(Refer to Fuel Delivery System - "High Pressure Fuel Pump".)

Installation

NOTICE

The fuel pressure regulator valve cannot be replaced as a unit. Replace it as high pressure fuel pump assembly.
(Refer to Fuel Delivery System - "High Pressure Fuel Pump".)