




Removal

1. Disconnect the negative (-) battery terminal.
2. If necessary, release the wiper blade fixing clip by pulling up and remove the wiper blade from the inside radius (A) of wiper arm.

Information


- Move the windshield glass wiper blades to the service position as follows;
After turning off the engine, move the wiper switch to the single wiping (MIST) position within 20 seconds and hold the switch more than 2 seconds until the wiper blade is in the service position.
- After turning ignition to the ON position, move the wiper switch to the single wiping (MIST) and wiper arms will return to the normal operating position.




3. Remove the cowl top cover.
(Refer to Body - "Cowl Top Cover")
4. Disconnect the wiper motor connector (A).




5. Remove the wiper motor & linkage assembly (A) after loosening the mounting bolts and nut.




6. Hold the wiper motor crank arm and remove the upper linkage (A).

**⚠ CAUTION**

- Before removing the wiper motor and linkage assembly, make sure that the linkage is stopped at auto stop position.
- To correctly install the wiper motor crank arm, check that the linkage is aligned with the crank arm in straight line and check the angle of each linkage.
- Be careful not to bend the linkage.




7. Remove the lower linkage (A) from the wiper motor crank arm.




⚠ CAUTION


- To correctly install the wiper motor crank arm, check that the linkage is aligned with the crank arm in straight line and check the angle of each linkage.
- Be careful not to bend the linkage.

8. Remove the crank arm (B) after loosening a nut (A).



9. Remove the wiper motor (A) after loosening the mounting bolts.





Installation

1. Install the wiper motor.
2. Install the crank arm.

Tightening torque :

14.7 - 19.6 N·m (1.5 - 2.0 kgf·m, 10.8 - 14.5 lb·ft)

CAUTION

To install the wiper motor crank arm, make sure that the linkage is aligned with the crank arm in straight line and set the angle of each linkages exactly.

3. Install the lower and upper linkage to the wiper motor crank arm.
4. Install the wiper motor and linkage assembly and then connect the wiper motor connector.

Tightening torque :

6.9 - 10.8 N·m (0.7 - 1.1 kgf·m, 5.1 - 8.0 lb·ft)

5. Install the cowl top cover.
6. Install the windshield wiper arm and blade.


Tightening torque :

22.5 - 26.5 N·m (2.3 - 2.7 kgf·m, 16.6 - 19.5 lb·ft)

NOTICE

The windshield wiper motor must be cycled to make sure that it is in the park position.
If necessary, adjust the wiper arm and blade.

7. Install the wiper arm and blade to the specified position.
Auto stop position (Blade)





Inspection

1. Remove the connector from the wiper motor.



No.	Description
1	-
2	IGN2
3	Wiper motor (Parking)
4	Wiper motor (High)
5	Ground
6	Wiper motor (Low)

2. Attach the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 5.

[Low Speed]**[High Speed]****Inspection (With KDS)**

1. In the body electrical system, failure can be quickly diagnosed by using the vehicle diagnostic system (KDS).
The diagnostic system(KDS) provides the following information.
 - (1) Self diagnosis : Checking failure and code number (DTC)
 - (2) Current data : Checking the system input/output data state
 - (3) Actuation test : Checking the system operation condition
 - (4) Additional function : Controlling other features including system option setting and zero point adjustment
2. Select the "Car model" and the "Intergated body control unit (IBU)" to be checked in order to check the vehicle with the tester.
3. Select the "Current Data" menu to search the current state of the input/output data.