

Please rate this document after reviewing at the bottom of this page.

DESCRIPTION

The cooling fan operates in 2 stages (HIGH/LOW). The ECM controls the cooling fan according to the coolant temperature, vehicle speed and A/C operation.

*** Thanks for your cooperation for the more quality. Please surely rate this document before closing.**