


Please rate this document after reviewing at the bottom of this page.

COMPONENTS



Torque : N·m (kgf·m, lb·ft, lb·in)

1. RH Cylinder head	11. High pressure fuel pump bracket
2. RH Cylinder head gasket	12. RH engine hanger
3. RH Camshaft thrust bearing cap	13. Center hanger
4. RH Camshaft bearing cap	14. MLA
5. RH Exhaust oil control valve (OCV)	15. Retainer lock
6. LH Cylinder head	16. Retainer
7. LH Cylinder head gasket	17. Valve spring
8. LH Camshaft thrust bearing cap	18. Valve stem seal
9. LH Camshaft bearing cap	19. Valve
10. LH Exhaust oil control valve (OCV)	

* Thanks for your cooperation for the more quality. Please surely rate this document before closing.