


Please rate this document after reviewing at the bottom of this page.

## COMPONENTS



### Torque : N·m (kgf·m, lb·ft, lb·in)

1. Air cleaner assembly (RH)	6. Air cleaner assembly (LH)
2. Air intake hose (RH)	7. Air intake hose (LH)
3. RCV hose (RH)	8. RCV hose (LH)
4. Air cleaner adapter (RH)	9. Air cleaner adapter (LH)
5. Air duct (RH)	10. Air duct (LH).

\* Thanks for your cooperation for the more quality. Please surely rate this document before closing.