


Please rate this document after reviewing at the bottom of this page.

COMPONENTS LOCATION



Tightening torque : N·m (kgf·m, lb·ft)

1. Inhibitor switch

2. Manual control lever

* Thanks for your cooperation for the more quality. Please surely rate this document before closing.