


Please rate this document after reviewing at the bottom of this page.

## COMPONENTS LOCATION



Tightening torque: N·m (kgf·m, lb·ft)

1. 27 brake control solenoid valve

2. Solenoid valve support bracket

\* Thanks for your cooperation for the more quality. Please surely rate this document before closing.