


Please rate this document after reviewing at the bottom of this page.

COMPONENTS LOCATION



Tightening torque: N·m (kgf·m, lb·ft)

1. UD clutch control solenoid valve

2. Solenoid valve support bracket

* Thanks for your cooperation for the more quality. Please surely rate this document before closing.