

Please rate this document after reviewing at the bottom of this page.

## DESCRIPTION

- R position solenoid valve is ON/OFF type.
- When TCM supplies current to solenoid valve, the solenoid valve operates and controls the R range.



**Solenoid Valve Operation Table**

	ON/OFF (R)
P	
N	
1	
2	
3	
4	
5	
6	
7	
8	
REV	•

\* Thanks for your cooperation for the more quality. Please surely rate this document before closing.