


Please rate this document after reviewing at the bottom of this page.

## COMPONENTS



**Tightening torque : N·m (kgf·m, lb·ft)**

1. Shock absorber	6. Spring upper cover
2. Spring lower pad	7. Strut bearing
3. Coil spring	8. Insulator assembly
4. Dust cover	9. Lock nut
5. Bumper stopper	

**\* Thanks for your cooperation for the more quality. Please surely rate this document before closing.**