

Please rate this document after reviewing at the bottom of this page.

---

## DESCRIPTION

---

- The front impact sensor (FIS) is installed in the Front End Module (FEM).
- FIS is a remote sensor that detects acceleration due to a collision at its mounting location.
- The primary purpose of the Front Impact Sensor (FIS) is to provide an indication of a collision. The Front Impact Sensor (FIS) sends acceleration data to the SRSCM.

\* Thanks for your cooperation for the more quality. Please surely rate this document before closing.

Cardiagn.Com