

Please rate this document after reviewing at the bottom of this page.

## REPLACEMENT

**⚠ CAUTION**

Do not apply sealant to the body.

1. Using a screwdriver, remove the tailgate lifter (B) after removing the socket clips (A).



2. Push the socket of the lifter into the bracket for installation.

**i** Information

Make sure the tailgate locks and opens properly and locks securely.

\* Thanks for your cooperation for the more quality. Please surely rate this document before closing.

English

Cardiagn.Com