





Component Location



1. Hood switch
2. Burglar horn
3. Integrated body control unit (IBU)
4. Door lock / unlock buzzer

5. Front door actuator & switch
6. Rear door actuator & switch
7. Liftgate actuator & switch