




Removal

1. Disconnect the negative (-) battery terminal.
2. Remove the vanity lamp (A) using a flat-tip screwdriver.



3. Disconnect the vanity lamp connector (A).



Installation

1. Connect the vanity lamp connector.
2. Install the vanity lamp.
3. Connect the negative (-) battery terminal.