


Components and Components Location



1. Horizontal light sensor

2. Vertical light sensor

3. Solar load sensor
4. Rain sensor (Left)

5. Rain sensor (Right)