




## Components



1. RH Cylinder head
2. RH Cylinder head gasket
3. RH Camshaft thrust bearing cap
4. RH Camshaft bearing cap
5. RH Exhaust oil control valve (OCV)
6. LH Cylinder head
7. LH Cylinder head gasket
8. LH Camshaft thrust bearing cap
9. LH Camshaft bearing cap
10. LH Exhaust oil control valve (OCV)

11. High pressure fuel pump bracket
12. RH engine hanger
13. Center hanger
14. MLA
15. Retainer lock
16. Retainer
17. Valve spring
18. Valve stem seal
19. Valve