




## Components



### Torque : N·m (kgf·m, lb·ft, , lb·in)

- |                    |                           |
|--------------------|---------------------------|
| 1. Intake manifold | 4. LH water gasket        |
| 2. Water hose      | 5. Intake manifold gasket |
| 3. RH water gasket |                           |