



Description

Via the seat belt/door switch, the ISG function can detect if the driver side seat belt is fastened and the driver side door is closed. If the driver side seat belt/door are not fastened/closed, the ISG system will not operate. If the seat belt/door are unfastened/opened, the engine will not start or stop by the ISG function for safety reasons.