



## Special Service Tools

Tool Name / Number	Illustration	Description
Fuel Pressure Gauge 09353-24100		Used for measuring the pressure in fuel line
Fuel Pressure Gauge Adapter 0K353-D4100		Used for connecting between high pressure fuel pump and low pressure fuel feed tube to measure the pressure in fuel line  ※ SST 09353-C1000 also can be used
Heated Oxygen Sensor Socket Wrench 09392-1Y100 (19 mm)		Removal and installation of the heated oxygen sensor  ※ SST No.09392-2H100 model also can be used for removing the Heated Oxygen Sensor.
Torque Wrench Socket 0K353-F6100 (17 mm)		Used for removing / installing high pressure fuel pipe
Injector Combustion Seal Guide & Sizing tool 09353-2B000		Used for installing injector combustion seal on injector
Injector Remover 09351-D2100		Removing the stuck injector
Sub Fuel Sender Plate Cover remover 09310-B9100		Used for removing / installing fuel pump.
Low Pressure Fuel Pump Plate Cover remover 09310-B8100		Used for removing / installing fuel pump.

