



Description

The system determines whether parking is active in the TCM by whether the S1 (P) pin and S2 (Not P) pin are ON or OFF, based on the working angle.

