




## Components



- 1. E module connector
- 2. Output speed sensor
- 3. Input speed sensor

- 4. Oil temperature sensor
- 5. Indirect control solenoid valve connector
- 6. Direct control solenoid valve connector