




## Components Location



### Tightening torque: N·m (kgf·m, lb·ft)

1. D position solenoid valve

2. Solenoid valve support bracket