



Description

- R position solenoid valve is ON/OFF type.
- When TCM supplies current to solenoid valve, the solenoid valve operates and controls the R range.



Solenoid Valve Operation Table

	ON/OFF
	(R)
P	
N	
1	
2	
3	
4	
5	
6	
7	
8	
REV	•