




Components



1. Input speed sensor
2. Output speed sensor
3. E-Module
4. Line pressure control solenoid valve
5. Damper clutch control solenoid valve
6. P position ON/OFF Solenoid valve
7. D position ON/OFF Solenoid valve
8. R position ON/OFF Solenoid valve

9. Parking release piston
10. 8LR/B control solenoid valve
11. 6/C control solenoid valve
12. 27/B control solenoid valve
13. 35R/C control solenoid valve
14. 4&OD/C control solenoid valve
15. UD/C control solenoid valve