





Components



1. Torque converter

2. Electric Oil Pump (EOP)

3. Parking switch (Inhibitor switch)

4. Main connector