


AWD ECU terminal function

[AWD ECU connector]



Pin	Description
1	Motor B
2	Motor A
5	Pressure sensor supply
7	IG1
8	Motor shield wire ground
9	Beterry ground
10	Beterry
14	Pressure sensor signal
15	Pressure sensor ground
17	CAN HIGH
18	CAN LOW