



Tightening Torques

Item		Tightening torque		
		N·m	kgf·m	lb·ft
Front	Wheel nut	107.9 - 127.5	11.0 - 13.0	79.6 - 94.0
	Drive shaft caulking nut	196.1 - 255.0	30.0 - 32.0	144.7 - 188.1
	Wheel speed sensor mounting bolt	6.9 - 10.8	0.7 - 1.1	5.1 - 8.0
	Hub assembly mounting bolt	88.3 - 107.9	9.0 - 11.0	65.1 - 79.6
	Lateral arm ball joint mounting bolt	88.3 - 107.9	9.0 - 11.0	65.1 - 79.6
	Compression arm ball joint mounting bolt	88.3 - 107.9	9.0 - 11.0	65.1 - 79.6
	Tie rod end ball joint mounting nut	88.3 - 107.9	9.0 - 11.0	65.1 - 79.6
Rear	Wheel nut	107.9 - 127.5	11.0 - 13.0	79.6 - 94.0
	Drive shaft caulking nut	294.2 - 313.8	30.0 - 32.0	217.0 - 231.5
	Shock absorber lower mounting bolt & nut	156.9 - 176.5	16.0 - 18.0	115.7 - 130.2
	Brake disc mounting screw	4.9 - 5.9	0.5 - 0.6	3.6 - 4.3
	Wheel speed sensor mounting bolt	6.9 - 10.8	0.7 - 1.1	5.1 - 8.0
	Hub assembly mounting bolt	88.3 - 107.9	9.0 - 11.0	65.1 - 79.6
	Upper arm front mounting bolt&nut	117.7 - 132.4	12.0 - 13.5	86.8 - 97.6
	Upper arm rear mounting bolt&nut	117.7 - 132.4	12.0 - 13.5	86.8 - 97.6
	Lower arm mounting bolt&nut	156.9 - 176.5	16.0 - 18.0	115.7 - 130.2
	Assist arm mounting bolt	156.9 - 176.5	16.0 - 18.0	115.7 - 130.2
	Trailing arm mounting nut	117.7 - 132.4	12.0 - 13.5	86.8 - 97.6
Propellershaft	Front propeller shaft mounting bolt	88.3 - 107.9	9.0 - 11.0	65.1 - 79.6
	Propeller shaft center bearing bracket mounting bolt	49.0 - 63.7	5.0 - 6.5	36.1 - 47.0
	Rear propeller shaft mounting bolt	88.3 - 107.9	9.0 - 11.0	65.1 - 79.6
Rear differential	Rear differential cover bolt	39.2 - 49.0	4.0 - 5.0	28.9 - 36.1
	Rear differential mounting bolt	68.6 - 88.3	7.0 - 9.0	50.6 - 79.6
Front differential	Front differential cover mounting bolts	58.8 - 63.7	6.0 - 6.5	43.4 - 47.0