







Special Service Tools

Tool Name / Number	Illustration	Description
Deployment tool 0957A-34100A		Used for deploying airbag
Deployment adapter 0K57A-3U100A		Used with the deployment tool (0957A-34100A) when deploying DAB, PAB, CAB, BPT, EFD
Deployment adapter 0957A-3F100		Used with the deployment tool (0957A-34100A) when deploying KAB
Deployment adapter 0957A-2W100		Used with the deployment tool (0957A-34100A) when deploying SAB
Dummy 0957A-38200		Simulator to check the resistance of airbag wiring harness
Dummy adapter 0957A-2W200		Used with the dummy (0957A-38200) when checking the resistance of SAB
Dummy adapter 0957A-3F000		Used with the dummy (0957A-38200) when checking the resistance of KAB
Dummy adapter 0957A-2G000		Used with the dummy (0957A-38200) when checking the resistance of DAB, PAB, CAB, BPT, EFD

DAB : Driver Airbag
PAB : Passenger Airbag
SAB : Side Airbag
CAB : Curtain Airbag
BPT : Seat Belt Pretensioner
EFD : Emergency Fastening Device
KAB : Knee Airbag