



Replacement


CAUTION

Put on gloves to protect your hands.


Information

- Use a plastic panel removal tool to remove interior trim pieces without marring the surface.
- Take care not to bend or scratch the trim and panels.

1. Remove the hood insulator pad (A) after removing the mounting clips.



2. Remove the hood garnish (A) after loosening the mounting nuts.



3. Install in the reverse order of removal.

i Information

Replace any damaged clips.