




Component Location



1. Steering column shroud upper panel

2. Steering column shroud lower panel