




Components



1. Cowl cross member bar
2. Main wiring
3. Main crash pad
4. Side air vent duct [RH]
5. Crash pad under cover [RH]
6. Crash pad lower panel [RH]
7. Crash pad center lower cover
8. Glove box housing
9. Fuse A/S cover
10. Crash pad garnish [RH]
11. Crash pad passenger side panel

12. Steering column lower shroud
13. Cluster fascia upper panel
14. Cluster assembly
15. A.V.N monitor
16. monitor fascia panel
17. Crash pad side switch
18. Crash pad garnish [LH]
19. Crash pad driver side panel
20. Side air vent duct [LH]
21. Center speaker grille