



Replacement

1. After loosening the mounting screw, remove the hood latch release handle (A).



2. Install in the reverse order of removal.

Information

- Make sure that the hood latch cable is connected properly.
- Make sure that the hood locks/unlocks and opens/closes properly.