



Replacement

⚠ CAUTION

Put on gloves to protect your hands.

ℹ️ Information

- Use a plastic panel removal tool to remove interior trim pieces without marring the surface.
- Take care not to bend or scratch the trim and panels.

1. Remove the inside rear view mirror cover (A).



2. Disconnect the inside rear view mirror connector (A).



3. Push the ECM mirror base down to remove the ECM mirror assembly (A).



4. Install in the reverse order of removal.

NOTICE

Be careful not to scratch the windshield glass.