



Component Location



1. Rear seat belt buckle [RH]

2. Rear seat belt buckle [LH]