



Replacement



CAUTION

Put on gloves to protect your hands.

Information

- Use a plastic panel removal tool to remove interior trim pieces without marring the surface.
- Take care not to bend or scratch the trim and panels.

1. Remove the caps (A) and screws, then remove the assist handle (B).



2. Install in the reverse order of removal.