



Replacement

NOTICE

Do not apply sealant to the body.

1. Remove the tailgate weatherstrip (A).



2. Install in the reverse order of removal.

Information

Install the weatherstrip aligned with center line .