



Description

AFS Unit (ECU)

AFS located in Cockpit Module is provided information of vehicle (steering wheel signal, vehicle speed, inclination of vehicle).

Based on provided information, it calculates algorithm and adjust Low beam of H/Lamp.

It transmits driving information by using LIN protocol, it is operated in Fail-safe reaction mode In case system failure occurred.