




## Component Location



- 1. Auto light sensor
- 2. Headlamps
- 3. Lighting switch (Auto)

- 4. Rear combination lamp
- 5. Integrated body control unit (IBU)