




Component Location



1. Fuel filler door open switch

2. Fuel filler door release actuator