




Component Location



1. Driver power window switch
2. Assist power window switch
3. Integrated central control unit (ICU)
4. Door lock knob
5. Liftgate actuator

6. Door latch assembly
7. Door lock/unlock switch
8. Rear left power window switch
9. Rear right power window switch