



Description


Heater Seat Smart Control Technology

- To prevent low temperature burn, seat heater temperature will automatically be lowered after a certain period of time.
(Low temperature burn condition: Over 30 minutes at 50°C)

Heater Seat Smart Control Operation


[1st Row Seat]

- Change to "MID" after 30 minutes in "HIGH", then "LOW" after 60 minutes in "MID"
- Change to "LOW" after 60 minutes in "MID"



[2nd Row Seat]

- Change to "MID" after 30 minutes in "HIGH", then "LOW" after 60 minutes in "MID"
- Change to "LOW" after 60 minutes in "MID"



Information

- If temperature is raised manually within certain period of time after the temperature was lowered automatically, it will be lowered again soon to prevent overheating or low temperature burn.
- This is normal operating condition as a safety device.