




Component Location



1. Integrated body control unit (IBU)

2. Interior antenna 1

3. Interior antenna 2

4. Liftgate open switch

5. Bumper antenna

6. Liftgate antenna

7. Buzzer

8. Start Stop Button (SSB)

9. Door handle & door antenna

10. FOB key