


Components



Connector Pin Function

Connector A

Pin NO	Function	Pin NO	Function
1	Battery (+)	13	IGN2
2	ILL (+)	14	ISG Power
3	-	15	IGN1
4	-	16	-
5	LIN BUS	17	-
6	-	18	-
7	HTD	19	-
8	-	20	-

9	Rear Defogging Switch	21	-
10	-	22	DETENT OUT(-)
11	-	23	-
12	ILL (-)	24	Ground