



Description

Located in the heater unit, the mode control actuator adjusts the position of the mode door by operating the mode control actuator according to the signal from the A/C control unit.

Pressing the mode select switch shifts the mode control actuator in the order of Vent → Bi-Level → Floor → Mix.