



Replacement

1. Discharge refrigerant from the refrigeration system.
2. Replace faulty tube or hose.

⚠ CAUTION

Cap the open fittings immediately to keep moisture or dirt out of the system.

3. Tighten the bolt or nut joint to the specified torque.

⚠ CAUTION

Connections should not be tightened to exceed the specified torque.

4. Evacuate air in the refrigeration system and charge system with refrigerant.

Specified amount

$600 \pm 25\text{g}$ ($21.1 \pm 0.88\text{oz.}$)

5. Inspect for leakage of refrigerant.

Using a gas leak detector, check for refrigerant leakage.

6. Inspect A/C operation.